



A1Touch Solution BV

Hogeweg 21
NL-6367 BA Voerendaal
The Netherlands

☎ : +31-(0)45 574 81 90
✉ : info@A1TouchSolution.nl
🌐 : www.A1TouchSolution.nl

Mounting full glass pcap panelmount touch monitor:

Before installation, please pay attention to the following things:

1. Make sure that the brackets on the left and right are removed first.
2. Make the hole for placing monitor at least as big as the dimension of monitor housing + at least 2.5mm all around.
3. If possible, try to place the cabinet / housing with the made hole horizontally so that the monitor can be placed vertically from above.
4. Gently lower the monitor into the hole. Make sure that the seals around the screen and the foil on the back are not damaged. Especially on the underside between monitor and glass plate under the kit is a flexcoil of the sensor. If it is cut through the sharp edge of the hole made, then the sensor will no longer work.
5. Now check whether the double-sided tape (still with protective film on it) that sits on the back of the glass panel is located everywhere on the cabinet / housing. If that is not the case, check the hole size for accuracy and possibly increase it slightly if the seal between monitor housing and glass plate is not free.
6. If the glass plate rests well on the double-sided tape everywhere, then the hole is good.
7. To be on the safe side, first test whether the touch monitor works properly.
8. If it gives an image and touches well everywhere, then the foil of the double-sided tape can be removed all around.
9. Make sure that the surface of the cabinet / housing where the glass plate comes on is properly degreased.
10. Place a track of silicone or a universal sealant such as Polymax all around on the inside of the double-sided tape (so between double-sided tape and monitor housing). Keep the height of approx. 2-3mm so that when pressed, it is well distributed over the surface between double-sided tape and monitor. Press the glass plate tightly all around so that the cabinet / housing sticks to the double-sided tape everywhere. Let the silicone / sealant dry for about 24 hours until a good adhesion is guaranteed.
11. Now place the left and right bracket on the inside of the cabinet / housing to prevent any theft of the screen.